Crockenhill Village Hall
Registered charity: 302724

HALL PLAN



E 1	Electrical distribution box (stage)
E 2	Spotlight controls
E 3	Electrical distribution box (Parish Council)
E 4	Electrical distribution box (Bar area)
E 5	Electrical distribution box (Kitchen supplies)
E 6	Main electrical distribution box electricity meter (in cupboard by vanity unit)
E 7	Car park light switch (in cupboard by vanity unit)
P 1	Stage power timed Mon- Friday & Saturday: Sun: 08:00 to 18:00 Sat: 08:00 to 23:45 Mon - Fri: 08:00 to 23:45
P 2	Stage power timed Mon- Friday & Saturday: Sun: 08:00 to 18:00 Sat: 08:00 to 23:45 Mon - Fri: 08:00 to 23:45

W 1	Water rising main (under vanity unit)
SW 1	Veranda light switch (Turn off when leaving hall)
SW 2	Coloured fairy lights (Turn off when leaving hall)
SW 3	Kitchen side wing lights (Turn off when leaving hall)
SW 4	Veranda side wing lights (Turn off when leaving hall)
SW 5	Main hall light control (Turn off when leaving hall)
S 1	Cleaning cupboard (Mops and brooms)
S 2	CVH committee storage
S 3	CVH committee + contact user storage
S 4	CVH committee + contact user storage
S 5	Table/chair storage (all tables + 8 stacks of 5 chairs)
H 1	Heating controls
G 1	Gas meter (under vanity unit)
G 2	Gas cooker isolation valve